



Jevndøgn 20. mars/oktober - 0900



20. mars/oktober - 1200



Vintersolverv 21. desember - 1200



20. mars/oktober - 1500



20. mars/oktober - 1800



21. desember - 1500



21. juni - 0600



21. juni - 0900



21. juni - 1200



21. juni - 1500



21. juni - 1800



21. juni - 2100